



ABI 3400 TAILWHEEL REPLACEMENT PARTS

ABI 3400 AND 3450 | ABI 3400-B BABY BUSHWHEEL

FIGURE	PART	PART NUMBER	
Figure 1	Tailwheel Head	ABI-3412-MK	
Figure 1A	2 Bolt Tailwheel Head	ABI-3450-23-M-K	
Figure 3	8" Fork	ABI-3413-01K	Scott/ABI 3400 Tailwheels
Figure 3A	10" Fork	ABI-3423-01K	Scott/ABI 3425/3450 Tailwheels
Figure 3B	Wide Fork	ABI-F2-K	ABI-3400-B Tailwheels
Figure 4	7/8" Head Spacer	ABI-3412-S.875	
Figure 5	15/16" Head Spacer	ABI-3412-S.937	
Figure 6	1" Head Spacer	ABI-3412-S1.00	
Figure 7	Bearing Race	8231	
Figure 8	Bearing	08118	
Figure 9	Compression Spring	ABI-3233-00	
Figure 10	Dust Cap, Upper	ABI-3411-02	
Figure 10A	Dust Cap, Upper	ABI-3411-07	For locking tailwheels only.
Figure 11	Thrust Washer	ABI-3408-00	
Figure 12	.036 Fiber Thrust Washer	3408-01	
Figure 12A	Fiber Thrust Washer	3479-01	For locking tailwheels only.
Figure 13	Bent Steering Arm	ABI-3410-03	
Figure 13A	Straight Steering Arm	ABI-3410-05	
Figure 14	Short Pawl	ABI-3219-00	
Figure 14A	Long Pawl	ABI-3219-02	
Figure 15	Spacer	ABI-3407-00	
Figure 16	.065 Fiber Thrust Washer	ABI-3408-02	
Figure 17	Dust Cap, Lower	ABI-3411-01	
Figure 17A	Dust Cap, Lower	ABI-3411-05	For locking tailwheels only.
Figure 18	Pin	232-046	
Figure 19	Compression Spring	ABI-3432-00	
Figure 20	Spacer	ABI-3258-01	
Figure 21	Spacer	ABI-3258-00	
Figure 22	Pin	ABI-3257-00	
Figure 23	Bearing Race	A4138	
Figure 24	Bearing	A4050	
Figure 25	Grease Retainer	ABI-1863	
Figure 26	Spacer	ABI-2504-01	
Figure 27	Washer Axle	960-816	
Figure 28	Nut	AN320-8	
Figure 29	Wheel Half	ABI-3244K	
Figure 29A	Wide Spacer	ABI-S2	ABI-3400-B Tailwheels
Figure 30	10" Axle Bolt	ABI-3236-C2	
Figure 30A	Wide Fork Axle Bolt	ABI-872	ABI-3400-B Tailwheels
Figure 31	Spacer	ABI-3227-00	

ABI 3400 TAILWHEEL REPLACEMENT PARTS

ABI 3400 AND 3450 | ABI 3400-B BABY BUSHWHEEL

FIGURE	PART	PART NUMBER	
Figure 32	Wheel Bolt	AN4-7A	
Figure 32A	Wide Wheel Bolt	AN4-34A	ABI-3400-B Tailwheels
Figure 33	Washer	AN960-416	
Figure 34	Nut	AN365-428A	
Figure 35	Tab Lock Washer	ABI-3225-00	
Figure 36	Washer	AN960-816L	
Figure 37	Nut	AN310-8	
Figure 38	Cotter Pin	MS246655-283	
Figure 39	Gasket	ABI-2602	
Figure 40	Zerk Fitting	T7201	
Figure 41	Zerk Fitting	T7208	
Figure 43	Bolt	AN5-32A	
Figure 44	Washer	AN960-516	
Figure 45	Washer	AN960-516L	
Figure 46	Nut	MS21044-N5	
Figure 47/48	8" Tire and Tube	280x2.50x4	Scott/ABI 3400 Tailwheels
Figure 47/48A	10" Tire and Tube	10x3.50-4	Scott/ABI 3425/3450 Tailwheels
Figure 47B	Baby Bushwheel	1154.R	ABI-3400-B Tailwheels

How to Order

1. Review the parts diagram to determine what items you need and take note of the figure number on the list above.
2. Go to the [3400 Replacement Parts](#) page to order through the website or call us at 907-331-4480 to order over the phone.

ALASKAN
BUSHWHEELS

ABI 3400 TAILWHEEL REPLACEMENT PARTS
ABI 3400 AND 3450 | ABI 3400-B BABY BUSHWHEEL