



ALASKAN
BUSHWHEELS

10" x 10" ABI WHEEL REPLACEMENT PARTS

FIGURE	PART	PART NUMBER
Figure 1	Inner Wheel Half	ABI-1010-01
Figure 2	Outer Wheel Half	ABI-1010-02
Figure 3	Bolt	AN5-36A
Figure 4	Bolt	AN4-35A
Figure 5	Seal Ring	ABI-153-00400
Figure 6	Inner Felt Seal	ABI-154-00300
Figure 7	Brake Disc (1.5" axle)	APS164-03601
Figure 7	Brake Disc (1.25" axle)	APS164-06700AB
Figure 8	Retaining Snap Ring	ABI-155-00100
Figure 9	Locknut	MS21044-N4
Figure 10	Locknut	MS21044-N5
Figure 11	Washer	AN960-416L
Figure 12	Washer	AN960-516L
Figure 13	Seal Ring	ABI-153-00300
Figure 15	Bearing Race	ABI-13836
Figure 16	Bearing Cone (1.25" axle)	ABI-13889-1.25
Figure 16	Bearing Cone (1.5" axle)	ABI-13889
Figure 17	Felt Grease Seal	ABI-154-01300

HOW TO ORDER

1. Review the parts diagram to determine what items you need and take note of the figure number on the list to the left.
2. Go to the 10" x 10" ABI Wheel Replacement Parts page to order through the website or call us at 907-331-4480 to order over the phone.

10" x 10" ABI WHEEL REPLACEMENT PARTS