



ALASKAN  
**BUSHWHEELS**

**ABI 40-60 WHEEL REPLACEMENT PARTS**

FIGURE	PART	PART NUMBER
Figure 1	Inner Wheel Half	ABI-161-07000
Figure 2	Outer Wheel Half	ABI-162-06500
Figure 3	Brake Disc	APS164-06700
Figure 4	Washer	AN960-416
Figure 5	Bolt	AN4-36A
Figure 6	Locknut	MS21044-N4
Figure 7	Seal Ring	ABI-153-00200
Figure 8	Inner Felt Grease Seal	ABI-154-02800
Figure 9	Retaining Ring	ABI-155-00200
Figure 10	Bearing Cone	ABI-08125
Figure 11	Bearing Race	ABI-08231
Figure 11	Outer Felt Grease Seal	ABI-154-00200

#### HOW TO ORDER

1. Review the parts diagram to determine what items you need and take note of the figure number on the list to the left.

2. Go to the ABI 40-60 Wheel Replacement Parts page to order through the website or call us at 907-331-4480 to order over the phone.

# ABI 40-60 WHEEL REPLACEMENT PARTS